

pc88

# Freestanding Four Door Fridge Freezer

Installation, Use and Maintenance

The logo for CDA, consisting of the letters 'C', 'D', and 'A' in a bold, red, sans-serif font, each letter enclosed in a thin white vertical line, all set against a black rectangular background.

## Important

The CDA Group Ltd cannot be held responsible for injuries or losses caused by incorrect use or installation of this product. Please note that CDA reserve the right to invalidate the guarantee supplied with this product following incorrect installation or misuse of the appliance.

Under no circumstances should any external covers be removed for servicing or maintenance except by suitably qualified personnel.

### **Appliance information:**

Please enter the details on the appliance rating plate below for reference, to assist CDA Customer Care in the event of a fault with your appliance and to register your appliance for guarantee purposes.

Appliance Model	
-----------------	--

Serial Number	
---------------	--


### **CE Declarations of Conformity:**

This appliance has been designed, constructed and marketed in compliance with safety requirements of EEC Directive 2006/95/EEC (Low voltage) and requirements of EMC Directive 2004/108/EEC.

This appliance has been manufactured to the strictest standards and complies with all applicable legislation, including Electrical safety (LVD) and Electromagnetic interference compatibility (EMC). Parts intended to come into contact with food conform to EEC/89/109.4.

## **IMPORTANT INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCE WITH EC DIRECTIVE 2002/96/EC.**

At the end of its working life, the product must not be disposed of as urban waste. It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service.

Disposing of a household appliance separately avoids possible negative consequences for the environment and health deriving from inappropriate disposal and enables the constituent materials to be recovered to obtain significant savings in energy and resources. As a reminder of the need to dispose of household appliances separately, the product is marked with a crossed-out wheeled dustbin .

## **Before First Use of the Fridge/Freezer**

**You must allow the fridge to settle for at least twenty four hours prior to switching the power on.**

It is recommended that you clean the interior of the appliance prior to first use, using a solution of bicarbonate of soda and warm water then thoroughly dry the interior.

**The fridge may have an odour to it at first use. This will disappear as the appliance cools.**

---

**Please note:**

The appliance will work continuously until it comes down to the correct temperature.

If the appliance is switched off, you should allow five minutes before switching it on again to prevent unnecessary damage to the compressor.

## Fridge Use

- Never put liquids in the refrigerator uncovered.
- Never put hot foods in the refrigerator. Warm food should be allowed to cool to room temperature before being put into the refrigerator.
- Nothing should rest against the rear wall of the refrigerator, as this will cause frost and possible condensation problems which will be difficult to remove.

## Freezer Use

- The freezer compartments are designed to store only frozen food.
- Never put hot or warm foods in the freezer, allow them to cool fully before putting them into the freezer.
- Follow the instructions on the food packaging for storage of frozen food. If no information is provided, foods should not be stored for more than three months after the purchase date.

# Control Panel

When the appliance is switched on the digital displays show the temperatures in the fridge and freezer compartments.




Fig. 1

## Setting the Fridge Temperature

- Touch the “OPTION” button several times, until the temperature for the fridge compartment flashes.
- Within five seconds of the fridge temperature starting to flash, touch the “▲” (up) or “▼” (down) keys until the required temperature flashes in the display (the temperature may be set in the range 2°C to 8°C).
- Either touch the “ENTER” key or wait until the display stops flashing to set this temperature.

## Setting the Freezer Temperature

- Touch the “OPTION” button several times, until the temperature for the freezer compartment flashes.
- Within five seconds of the freezer temperature starting to flash, touch the “▲” (up) or “▼” (down) keys until the required temperature flashes in the display (the temperature may be set in the range -24°C to -16°C).
- Either touch the “ENTER” key or wait until the display stops flashing to set this temperature.

# Holiday Mode

This appliance is equipped with a holiday mode function, which will switch the fridge off and leave the freezer running. This maintains frozen food during a holiday, without running the fridge as well.

## **To switch the holiday mode on**

- Touch the “OPTION” button several times, until the “OFF” light in the fridge temperature display flashes.
- Within five seconds of the ”OFF” light starting to flash, touch the “ENTER” key to set this function.
- The “OFF” light remains lit and the fridge temperature is not lit to show that the fridge section is switched off.

**Note that when the “OFF” light is lit this means that the holiday mode is ON.**

## **To switch the holiday mode off**

- Press the “OPTION” button several times, until the “OFF” light in the fridge temperature display flashes.
- Within five seconds of the ”OFF” light starting to flash, touch the “ENTER” key to switch the vacation mode off.
- The fridge temperature is lit to show that the fridge section is switched on again.

# Quick Freeze Function

The quick freeze function can be used to freeze large quantities of fresh food as quickly as possible. This function can be set for a specific duration before automatically switching off for your convenience. For best results, switch the quick freeze function on 12 hours prior to introducing large quantities of food to be frozen.

## To switch the quick freeze function on

- Touch the “OPTION” button several times, until the quick freeze light “❄️” flashes.
- Within five seconds of the quick freeze light “❄️” starting to flash, touch the “ENTER” key to confirm it. The display starts flashing the optional quick freeze duration (defaults to one hour).
- Within five seconds of the display starting to flash, touch the “▲” (up) or “▼” (down) keys until the required time flashes in the freezer display (the time may be set in the range 1 to 26 hours).
- Touch the “ENTER” key to confirm the setting.
- The freezer temperature display will show -32°C to indicate that the fast freeze function is active.

**Note that if the keys are not touched within the required time the freezer may be set to quick freeze mode with no end time defined: In this case the freezer should not be left in this mode for more than 48 hours at a time.**



### **To switch the quick freeze function off**

- Touch the “OPTION” button several times, until the quick freeze light “❄️” flashes.
- Within five seconds of the quick freeze light “❄️” starting to flash, touch the “ENTER” key to switch the quick freeze function off.
- The Freezer temperature reverts back to what it was before the fast freeze was activated.

## **Auto Mode**

This appliance is equipped with an “Auto” mode, which sets the fridge temperature to 5°C and the freezer temperature to -18°C.

### **To switch the auto mode on**

- Touch the “OPTION” button several times, until the “AUTO” light in the display flashes.
- Within five seconds of the “AUTO” light starting to flash, touch the “ENTER” key to set this function.
- The “AUTO” light remains lit and the temperatures switch to those defined above.

### **To switch the auto mode off**

- Press the “OPTION” button several times, until the “AUTO” light in the display flashes.
- Within five seconds of the “AUTO” light starting to flash, touch the “ENTER” key to switch this function off.
- The fridge and freezer temperature settings revert back to what they were before the auto mode was activated.

---

## Door Open Alarm

This appliance is equipped with an alarm to alert you if a door is left open.

In the event that a door is left open for more than approx. two minutes the appliance will start beeping and the “ALARM” light will illuminate; this continues until all doors are properly shut.


## Defrosting the Fridge

The fridge is self-defrosting. Any water created will run out of the fridge through the channel at the back of the fridge. It is important to keep the channel clear at all times. The defrosted water is collected in the evaporating tray at the back of the appliance.

## Defrosting the Freezer

**Do not use heaters or defrosting sprays in this appliance.**

- Never use any metallic or sharp objects to remove the ice as this could damage the lining.
- The freezer compartment should be defrosted regularly to ensure the most efficient running of the freezer.
- Once the ice is more than 5 mm thick, the freezer must be defrosted.
- First remove the freezer drawers.
- To speed up the process, put a bowl of warm water in the base of each freezer compartment.
- Once defrosting is complete, dry the inside of the freezer compartment with a sponge or clean cloth.



# Care and Cleaning

**Always disconnect the appliance from the power before any cleaning or maintenance.**

- The refrigerator and freezer sections should be cleaned using a solution of bicarbonate of soda and lukewarm water.
- Do not use abrasive products or detergents. After washing, rinse and dry thoroughly.
- Clean the shelves and balconies separately by hand using soap and water. Do not put them in the dishwasher.
- The evaporating tray and water drain hole (at the back of the refrigerator compartment) should be cleaned periodically to prevent the defrosted water from collecting inside the refrigerator compartment. The drain plug can be used to clear the drain hole.
- Once cleaning is complete, then reconnect the power.
- If the appliance is not used for prolonged periods of time, unplug and clean it. The doors should be left slightly open to prevent the formation of mildew and smell.

**This appliance must never be installed close to heat sources, e.g. heating elements and cookers or in damp places.**

- The plug should be fully accessible at all times.
- To ensure the appliance is level, you should use the height adjustable feet at the front of the appliance.
- The cooling system at the rear of the appliance must not touch the rear wall.

- The appliance must be installed with adequate ventilation. Ensure that there is 10cm clearance above the appliance, and that there is space between the rear of the appliance and the wall.

## Troubleshooting

If you have any problems with your appliance, you should check the troubleshooting prior to calling CDA Customer Care, to prevent unnecessary service calls and potential cost.

### **If the appliance is not working**

- Check there is power to the appliance.
- The control panel is lit.
- The house fuses are intact and the fuse in the plug has not blown.
- The fridge is not in holiday mode.
- The plug socket is functioning correctly. To check this, plug another electrical appliance in to see if the socket is working.

### **The appliance is working, but not very well**

- The appliance is not overloaded.
- The temperature is set to an appropriate level.
- The doors are closing properly.
- The cooling system at the rear of the appliance is clean and free of dust, and not touching the rear wall.
- There is enough ventilation at the side and rear walls.

---

### **The appliance is noisy**

- The appliance is level and stable.
- The side and rear walls are clear, and there is nothing resting on the appliance.
- The cooling gas in the refrigerator will make a slight bubbling noise, even when the compressor is not running.


### **There is water in the lower part of the refrigerator compartment**

- The drain hole in the channel at the back of the compartment is clear.

# Installation and Ventilation

**This appliance must never be installed close to heat sources i.e. heating elements and cookers or in damp places**


Failure to provide adequate ventilation can lead to increased running costs and premature failure; it may also invalidate the warranty provided with the product.



- Ensure ventilation openings are kept clear.
- Do not use a multi-plug adaptor in the socket to connect this appliance alongside other appliances.
- Do not tilt the fridge beyond 45°.
- Do not exert excessive pressure on the appliance.
- Locate the appliance in a well ventilated position, away from heat sources, damp and direct sunlight.
- Ensure that there is a gap of no less than 10cm above and to the sides of the appliance to allow for ventilation. The clearance between the sides and adjacent furniture will also allow the doors to open fully.
- A gap of 5cm should be allowed for ventilation between the rear wall and the back of the appliance.

# Electrical Information

**Warning! This appliance must be earthed.**



The mains lead of this appliance has been fitted with a BS 1363A 13A fused plug. To change a fuse in this type of plug, follow the steps below:

1. Remove the fuse cover and fuse.
2. Fit replacement 13A fuse, ASTA approved to BS 1362 type, into the fuse cover.
3. Replace fuse cover.

**Important: do not use the appliance without the fuse cover in position.**

## How to connect an alternative plug

If the fitted plug is not suitable for your socket outlet, then it should be cut off and disposed of safely to avoid possible shock hazard. A suitable alternative plug of at least 13 Amp rating to BS 1363 should be used.



As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:-

- The wire which is coloured GREEN and YELLOW must be connected to the terminal which is marked with letter (E) or by the Earth symbol  $\perp$  or coloured GREEN and YELLOW.
- The wire which is coloured BLUE must be connected to the terminal which is marked with the letter (N) or coloured BLACK.
- The wire which is coloured BROWN must be connected to the terminal which is marked with the letter (L) or coloured RED.

If in doubt regarding the electrical connection of this appliance, consult a qualified electrician. Do not shorten the supply cable, the appliance may require removing for servicing.

**N.B. Ensure that the plug socket is situated in an easily accessible place.**

**If the power supply cable is damaged, it must be replaced by a CDA authorised agent.**

---

## NOTES

---

## NOTES



Please contact our **Customer Care Department** for Service on the details below

**Customer Care Department**

The CDA Group Ltd. • Harby Road • Langar • Nottinghamshire • NG13 9HY  
T : 01949 862 012 F : 01949 862 003 E : customer.care@cda.eu



[www.cda.eu](http://www.cda.eu)